


# VIBE

## Bluetooth Speaker

### User Manual




製品說明書

中文 / English / 日本語

## 喇叭介紹

### 1 本體

- ① 被動盆
- ② 功能鍵
- ③ 音量-
- ④ 音量+
- ⑤ 播放鍵
- ⑥ 音箱腳墊
- ⑦ 攜帶繩
- ⑧ 藍牙鍵/燈
- ⑨ 電源鍵/燈
- ⑩ USB-C 充電口



## 按鍵說明

### 1 開機/關機

#### a.開機

關機狀態下,長按電源鍵3秒,開機提示音響起,電源燈號亮起。

長按電源鍵「」3秒



#### b.關機

開機狀態下,長按電源鍵3秒,聽到關機提示音,電源燈號熄滅。

## 配對模式

▽ 請開啟裝置的藍牙功能,並搜尋藍牙裝置:


**iOS:** 設定 > 開啟藍牙,開啟後會自動搜尋藍牙裝置  
**Android:** 設定 > 開啟藍牙 > 搜尋藍牙裝置

▽ 藍牙裝置搜尋到:"XROUND VIBE",請點選配對。

▽ 點選後請按確認配對。配對完成後,會出現"Connected"語音提示,即完成配對。

▽ 配對完成後,藍牙燈號為橘燈恆亮,即完成配對步驟。

※新裝置:開機將自動進入配對模式。此時藍牙燈號為藍綠燈閃爍。  
※強制配對:長按藍牙鍵3秒,進入配對模式,並出現Pairing的語音提示。



## 立體聲模式


▽ 先將一個喇叭,同時長按藍牙鍵與功能鍵3秒,此時將進入立體聲配對模式。聽到"Stereo Mode Pairing"提示音後。

▽ 再取另外一個喇叭重複上面操作,若喇叭都進入立體聲配對模式將會自行配對,聽到"Stereo mode connected"提示音,即為配對成功。\*左喇叭會有 Left 提示音,右喇叭會有 Right 提示音。

※立體聲模式下:藍牙燈號顯示為藍燈,單顆為橘燈。  
※預設狀態下:主喇叭為左耳,可透過 APP 調整左右聲道。  
※若兩組喇叭重新開機會自動回連成立體聲模式。

**取消立體聲配對**

立體聲模式下,同時長按藍牙鍵&功能鍵2秒即可解除模式。



# VIBE

## Bluetooth Speaker

## LE Audio 派對模式

▽ 按藍牙鍵三下,可切換一般模式/ LE AUDIO派對模式。此模式可以將數支 VIBE 喇叭同時播放一樣的訊源,此時藍牙燈號為綠燈恆亮。

※此模式不支援一般傳統藍牙,需要搭配支援 LE audio 廣播規格的藍牙(BIS)發射器。如: XROUND Thunder Connect™ PRO 電競發射器。(需升級該發射器韌體)

※此模式,可長按音量+/-,來切換 LE Audio 訊源。

※派對模式下,不影響單隻/立體聲模式使用。

## 充電說明

- 請使用原廠充電線充電。
- 充電指示燈說明:充電時電源燈號為慢閃。
- 充滿電後電源燈號將熄滅。

電池電量 充電盒指示燈

1~25% 紅燈

25~50% 橘燈

50~100% 白燈

## 其他操作

### 語音助手

長按功能鍵2秒。

### 強制開機

音量+ / 音量- / 播放鍵,三鍵同時按。

### 恢復原廠模式

長按電源與藍牙按鍵10秒,藍牙燈與電源燈同時交叉閃爍代表回復為原廠模式。

## 產品規格

藍牙版本 Bluetooth® 5.3

藍牙規格 Class 1

傳輸距離 15 m / 無障礙空間最大 80m

支援藍牙編碼 SBC·AAC·LDAC

支援傳輸協定 AVRCP1.6 / HSP1.2 / HFP1.7 / A2DP1.3.1/LC3

單體規格 絲質高音單元、中低頻圓單體

頻率響應 80-40,000 Hz

麥克風 1\* MEMS

電池續航力 喇叭本體:15HR ※以 AAC 編碼,音量 50% 測試

充電介面 USB-C

充電時間 2小時40分(單) ※完全沒電到滿電時間  
※支援快充功能:充電約15分鐘,可使用約1.5小時

防水防塵等級 本體 IP67

內容物 VIBE 喇叭 單入組\*1組 / 2入組\*2組  
USB-C 充電線 單入組\*1條 / 2入組\*2條  
快速指南

## 安全與操作提醒

為顧及耳機使用壽命與使用安全,請遵守以下事項:

- 請勿摔落或是拋擲喇叭。
- 請勿暴露在潮濕、多塵、或是溫度高於攝氏 51 度環境。
- 使用本喇叭以高音量聆聽可能會影響聽力。請將音量調整到可接受之最低音量。
- 為了交通安全,請勿在開車或騎乘車時使用本喇叭。
- 在鐵路平交道、車站月台、人行穿越道及工地等,請勿使用喇叭。
- 請使用柔軟的纖維布清潔喇叭。
- 充電後,請斷開充電線材,以維持電池使用壽命。
- 請使用原廠或是經認證的連接線材充電。
- 喇叭及其配件可能包含小零件。請將產品放置於孩童無法觸及之處。以免發生誤食危險。
- 藍牙訊號在以下環境下容易受到干擾:
  - ➔ 附近有多個 Wi-Fi 訊號或是藍牙訊號的環境
  - ➔ 機場、高鐵、地鐵等電磁干擾較大的環境

## 電池安全

- 請使用符合 CE 規範的充電器充電。
- 請勿改裝或拆解電池,插入異物、浸入水中或其他液體,以免電池漏液、過熱或起火爆炸。
- 本設備有不可拆卸內置電池,請勿拆卸產品或改裝電池,避免電路故障導致起火或是觸電。
- 請依照所在當地的要求與說明處理廢棄電池。

## 有限保固須知

親愛的客戶,親愛的客戶,感謝您購買 VIBE 藍牙喇叭。XROUND Inc.保證本產品沒有材料或工程缺陷,若有例外情況或問題,請閱讀以下條款:

保固期限為購買日或產品出貨日起算一年以內。當您的有限保固過期,法律上的所有保固期也將過期。

本產品對於以下情況導致的任何缺陷、故障或失靈概不負責:

- 1.由於錯誤操作、濫用、人為疏忽等所導致的電子、機械、外殼或各種零件之損害。
- 2.由不可抗力或是自然力、天災導致的損害。
- 3.由未經授權的維修中心或人員進行不恰當的修理。

## 其他注意事項


- 本保固期從您的新品購買日或是產品出貨日起算一年內有效,可能會視情況需要提供購買或保固證明以利客服人員確認。
- 若有產品保固/保修上的問題,請聯絡當地經銷商協助處理,經銷商資訊詳見官方網站。

※警語:低功率射頻器材技術規範  
取得審驗證明之低功率射頻器材,非經核准,公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。  
低功率射頻器材之使用不得影響飛航安全及干擾合法通信;經發現有干擾現象時,應立即停用,並改善至無干擾時方得繼續使用。  
前述合法通信,指依電信管理法規定作業之無線電通信。  
低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

## SPEAKER INTRODUCTION

### 1 Speaker

- ① Passive Radiator
- ② Function Button
- ③ Volume +
- ④ Volume -
- ⑤ Play / Pause
- ⑥ Pad
- ⑦ Carrying Rope
- ⑧ Bluetooth Button
- ⑨ Power Button
- ⑩ USB-C Charging Port



## USER GUIDE

### 1 POWER ON / OFF

#### a.Power On

In the power-off state, press and hold the power button for 3 seconds, you can hear a power-on prompt sound and the power indicator light will turn on.

press 3s



#### b.Power Off

In the power-on state, press and hold the power button for 3 seconds, you can hear a power-off prompt sound and the power indicator light will turn off.

## Pairing

▽ Turn on the Bluetooth function of your device and search for nearby Bluetooth devices.

**iOS:** Settings > Bluetooth On. iOS will automatically search for Bluetooth devices.

**Android:** Settings > Bluetooth On > Search for Bluetooth devices.

▽ Select "XROUND VIBE" in the Bluetooth searching list of your device.

▽ When the pairing is completed, you will hear the "Connected" audio prompt. The Bluetooth light flashing orange.

※New Device: When powered on the speaker, it will automatically enter pairing mode with the Bluetooth light flashing blue and green.

※Forced Pairing: Press and hold the Bluetooth button for 3 seconds to force the speaker entering pairing mode.




## Stereo Mode

※Pair two speakers to create a stereo speaker set.  
※Operate through the app or by using button controls.

▽ First, press and hold the Bluetooth button and the function button on one speaker for 3 seconds to enter stereo pairing mode.

▽ After hearing the "Stereo Mode Pairing" prompt, repeat the same operation on the other speaker. If both speakers enter stereo pairing mode, they will pair automatically. You will hear "Stereo mode connected" when the pairing is successful. \*The left speaker will have a "Left" prompt, and the right speaker will have a "Right" prompt.



※ In stereo mode, the Bluetooth indicator light will be blue. For a single speaker, it will be orange.  
※ By default, the main speaker is set to the left channel, but you can adjust the left and right channels through the app.  
※ If the pair of speakers are restarted, they will automatically reconnect in stereo mode.

### Cancel stereo pairing

Under stereo mode, simultaneously press and hold the Bluetooth button & Function button for 2 seconds to exit stereo mode.

## LE Audio Party Mode

▽ Pressing the Bluetooth button three times toggles between Normal Mode and LE Audio Party Mode. This mode allows multiple VIBE speakers to play the same audio source simultaneously, and the Bluetooth indicator light remains solid green for party mode.

- ※ Party mode does not support classic Bluetooth and requires a Bluetooth (BIS) transmitter that supports the LE audio broadcasting standard, such as the XROUND Thunder Connect™ PRO gaming transmitter (firmware upgrade required).
- ※ You can switch LE Audio sources by long-pressing the volume +/- buttons in party mode
- ※ Both single and stereo modes can enter party modes.

# VIBE

## Bluetooth Speaker

### User Manual

English



## Charging Instructions

Please use the official charging cable for charging.

**Charging Indicator Light Explanation:** During charging, the power indicator light flashes slowly.

A white light indicates battery level above 50%, an orange light indicates battery level between 50% to 25%, and a red light indicates battery level below 25%.

Once fully charged, the power indicator light will turn off.

Battery Level	Status of Battery Indicator
1-25 %	Red light
25-50%	Orange light
50-100%	White light

## OTHER OPERATIONS

### Voice Assistant

Long-press the function button for 2 seconds.

### Forced Shutdown

Press and hold the volume +, volume -, and play buttons simultaneously to force shutdown the speaker.

### Factory Reset

Long-press the power and Bluetooth buttons for 10 seconds. When the Bluetooth and power indicator lights flash alternately, it indicates that the speaker has been factory reseted.

## PRODUCT SPECIFICATIONS

<b>Bluetooth Version</b>	Bluetooth® 5.3
<b>Bluetooth Specification</b>	Class 1
<b>Wireless Range</b>	15 m / Maximum 80m for barrier free area
<b>Bluetooth Codec</b>	SBC-AAC-LDAC
<b>Bluetooth Profile Support</b>	AVRCP1.6 / HSP1.2 / HFP1.7 / A2DP1.3.1/LC3
<b>Driver</b>	Silk Dome Tweeter and Elliptical Mid-Bass Driver
<b>Frequency Response</b>	80-40,000 Hz
<b>Microphone</b>	1* MEMS
<b>Battery Life</b>	15 hours *Tested by AAC codec, 50% volume
<b>Charging Specification</b>	USB-C ※ From 0% to 100% ※Support quick charging : Charge 15 min can use for 1.5 hours
<b>Charging Time</b>	2 HR 40 min
<b>IP Rating</b>	IP67
<b>Contents</b>	VIBE Bluetooth Speaker : Single Unit Set * 1 pcs / Two Unit Set * 2 pcs USB-C cable : Single Unit Set * 1 pcs / Two Unit Set * 2 pcs Quick Start Guide

## SAFETY AND OPERATING GUIDELINES

To ensure the longevity and safety of your speaker, please adhere to the following guidelines:

- Do not drop or throw the speaker.
- Avoid exposure to humid, dusty, or environments with temperatures exceeding 51 degrees Celsius.
- Listening to the speaker at high volumes may affect your hearing. Adjust the volume to a comfortable level.
- For safety while driving or riding, do not use the speaker.
- Avoid using the speaker at railway crossings, train platforms, pedestrian crossings, and construction sites.
- Clean the speaker with a soft fiber cloth.
- Disconnect the charging cable after fully charging to extend battery life cycle.
- Use original or certified charging cables.
- Keep small parts of the speaker and its accessories out of reach of children to prevent choking hazards.
- Bluetooth signals may suffer from interference in the following environments:
  - Multiple Wi-Fi signals or Bluetooth connection in the same area
  - Airports, Express Railway, Metro, and similar areas with high electromagnetic interference

## BATTERY SAFETY

- Use chargers that comply with CE standards.
- Do not modify or dismantle the battery, insert foreign objects, submerge in water, or liquids to avoid leakage, overheating, or fire hazards.
- Do not modify or dismantle the battery, insert foreign objects, submerge in water, or liquids to avoid leakage, overheating, or fire hazards.
- Dispose used batteries in accordance with local requirements and instructions.

## LIMITED WARRANTY

This warranty is valid for one year from the date of your new purchase or product shipment and may require proof of purchase or warranty for customer service verification.

For any warranty issues, please contact your local distributor for assistance. Distributor information can be found on the official website.

## LIMITED WARRANTY

Dear customer,

Thank you for purchasing AERO PRO True Wireless Earbuds. We trust this product will fulfill all your needs and expectations. Should there be a problem, please read the warranty condition below :

XROUND Inc. warrants this product for a period of one year from the date of original purchase or date of shipment of new, unused equipment.

Upon the expiration of the warranty period, XROUND no longer provides any repairs/replacements.

This warranty does not cover any defects, failures, or malfunctions caused by the following conditions:

- Damages to the device and various parts resulting from incorrect operation, abuse, and human negligence.
- Damage caused by force majeure or natural disasters.
- Improper repairs by unauthorized repair centers or personnel.



## ペアリング

※新しいデバイス:本体の電源がONになっている場合、自動的にペアリングモードになります。この時Bluetooth ボタンが青と緑に点滅します

※強制ペアリング:Bluetooth ボタンを3秒長押しするとペアリングモードになります。

デバイスのBluetooth機能を有効にし、Bluetoothデバイスを検出できる状態にします。

**iOS:** 設定 > Bluetoothをオンにする > 自動的にBluetoothデバイスを検出します。

**Android:** 設定 > Bluetoothをオンにする > Bluetoothデバイスを検出します。

接続するデバイスのBluetooth画面に"XROUND VIBE"が表示されたら選択します。

選択したら"ペア設定する"を選択してください。ペアリングが完了すると、音声で"Connected"とお知らせします。

この時Bluetooth ボタンがオレンジに点灯します。イヤホンを充電ケースから取り出せば、デバイスと接続された状態になっています。



## ステレオモード

※2つのスピーカーをペアリングしてステレオ再生する。 ※ステレオペアリング:アプリもしくはボタンで操作。

スピーカーを接続し、Bluetoothボタンとファンクションボタンを3秒長押しするとステレオモードになります。

"ステレオモード ペアリング"と音声 flowed after another 1 of the speaker with the operation described above, 2 of the speaker's pairing is completed and "Stereo Mode Connected" and sound together connection is completed. \*Left speaker is Left of the sound, right speaker is Right of the sound is regenerated.

※ステレオモードでは Bluetoothランプは青色に点灯し、モノラルではオレンジに点灯します。 ※デフォルトではメインスピーカーは左側に設定されていますが、アプリで左右のサウンドを設定することができます。 ※2つのスピーカーを再起動すると自動的にステレオモードになります。

### ステレオペアリングキャンセル

ステレオモード中にBluetoothボタンとファンクションボタンを同時に2秒長押しするとステレオモードが解除されます。

## LEオーディオ パーティーモード

Bluetoothボタンを3回タップすると 通常モード / LEオーディオパーティーモードの切り替えが可能です。 このモードでは複数のVIBEスピーカーが同じメディア音声を再生することができます。この時Bluetoothランプが緑色に点灯します。

※パーティーモードは従来のBluetoothに対応しておらず、XROUND Thunder Connect™ PRO ゲーミングトランスミッターなどのLE オーディオ規格対応のトランスミッターとのペアリングが必要です。(トランスミッターのファームウェアアップデートを行ってください。)

※パーティーモード中に 音量 +/- ボタンを3秒間長押しすることでLEオーディオへの切り替えが可能です。

※パーティーモードは シングル / ステレオ モードどちらでもご利用いただけます。

## 製品規格

<b>Bluetooth バージョン</b>	Bluetooth® 5.3
<b>Bluetooth 規格</b>	Class 1
<b>最長接続距離</b>	15 m / 通信障害物なしの場合 最大 80m
<b>Bluetooth 対応コーデック</b>	SBC, AAC, LDAC
<b>対応プロトコル</b>	AVRCP1.6 / HSP1.2 / HFP1.7 / A2DP1.3.1/LC3
<b>ドライバー</b>	シルクドームツイーター、中低域楕円ドライバー
<b>周波数</b>	80-40,000 Hz
<b>マイク</b>	1* MEMS
<b>バッテリー持続時間</b>	15 時間 ※コーデックAAC, 音量 50% で測定
<b>インターフェイスコネクタ</b>	USB-C
<b>充電時間</b>	2 時間 40 分 ※バッテリー残量 0% から 100% まで ※クイックチャージ対応: 15 分の充電で 1.5 時間使用可能
<b>IP 保護等級</b>	本体 IP67
<b>パッケージ内容</b>	VIBE Bluetooth スピーカー : シングルユニットセット * 1個 / ダブルユニットセット * 2個 USB-C ケーブル : シングルユニットセット * 1本 / ダブルユニットセット * 2本 クイックスタートガイド

## 安全と操作上の注意

本製品を長く安全にご使用頂くために、以下の事項をお守りください:

- スピーカーを落としたり投げたりしないでください。
- 湿気やほこりの多い場所、または51°C以上の高音の環境に晒さないでください。
- 当製品を大音量でご使用されると聴力を損なう恐れがあります。できる限り音量を控えめに調節してご使用ください。
- 交通による事故を防ぐため、運転中や乗車中のご使用はおやめください。
- 電車の踏切や駅のプラットフォーム、横断歩道、工事現場などでは当製品を使用しないでください。
- お手入れをされる場合は柔らかい布をお使いください。
- バッテリー使用寿命維持のため、充電が完了したらケーブルは取り外してください。
- 充電は純正品または認証を受けた正規のケーブルで行ってください。
- スピーカー及びその他の部品には小さな部品が使われています。誤って口に入れたりしないよう、お客様の手の届くところに放置しないでください。
- Bluetooth通信は以下の環境下では干渉を受けやすくなりますのでご注意ください:
  - 近辺に複数のWi-FiやBluetoothなどの電波が飛び交う環境
  - 空港、高速鉄道、地下鉄等の比較的電磁波の干渉が大きい環境

## 電池を安全にご使用いただくために

- 充電にはCEマークの基準を満たす充電器をご使用ください。
- 電池の液漏れ、発熱、発火、爆発などの原因となりますので、電池を改造したり分解したり、異物を入れたり、水やその他の液体に浸したりしないでください。
- 本製品には取り外し不可能なバッテリーが内蔵されています。回路故障による火災や感電を防ぐため、製品を分解したり、バッテリーを改造したりしないでください。
- 廃バッテリーはお住いの地域や自治体の指示に従って処分してください。

## 製品保証について

このたびはVIBE Bluetooth スピーカーをご購入いただき誠にありがとうございます。XROUND Inc.では製品の材料および製造工程に万全を期しておりますが、何か問題がございましたら以下をご参考ください: 保証期間はご購入の日またはお受け取りの日から起算して一年以内です。保証期間を超えた場合、法律上の保証期間も過ぎているものとみなします。

下記の状況によって引き起こされたいかなる瑕疵、故障または不具合はいずれも弊社 の責任・保証対象外となります:

- 誤った操作、乱用、人的過失等で生じた電子部品、機械、外装または各種部品の損。
- 不可抗力または自然、天災による損傷。
- 製造者の認証を受けていないメンテナンスセンターまたは人員による不適切な修理。

## その他

### ボイスアシスト

ファンクションボタンを2秒長押し。

### 強制シャットダウン

音量+ボタン、音量-ボタン、再生 / 停止ボタンの3つを同時に押すとスピーカーの電源が強制的にOFFになります。

### リセット

電源とBluetoothボタンを10秒程長押しすると電源とBluetoothランプが同時に点滅し、工場出荷時の状態にリセットされます。

## その他の注意事項

保証期間はご購入の日またはお受け取りの日から起算して一年以内です。ご購入または保証についての証明の添付を求められる場合があります。

当製品に関する製品保証や修理についてのご質問は、お買い上げになった取扱販売者にご連絡ください。販売代理店に関する詳しい情報は公式ウェブサイトをご覧ください。

